





Carving Instructions



Trim the pattern and tape it to your pumpkin. Make pattern fit smoothly by folding on the crease lines shown on the pattern. Tape the folds in place.



Use the pounce wheel to transfer the pattern, rolling along the lines. When the design is completely transferred, remove the paper pattern.



Hold carving tip carefully. With the dull side facing outward, slowly slide into handle tip. The sharpened side should be facing toward the handle.
To remove: Holding the handle upside-down, gently press the tip downward from the top of the handle.



Hold pumpkin in lap for ease and control of carving. For the outline of your design use the "V" tip to carve. Starting at the top of your design, insert tool and gently pull handle along center of design lines. Carve in short segments, using your fingers as a guide and for leverage against the pumpkin skin as shown.



Use the square shaped tip to remove large areas of pumpkin skin and smooth carved areas. Use the U-shaped tip to follow curves and details within your design.



Display!

Carving Tools



The Surface Carving Handle
easy to grip handle allows for quick surface carving patterns.



The Surface Carving Tips
quickly attach to the Surface Carving Handle to create three unique designs.



The Pounce Wheel
is used to transfer patterns onto pumpkins by rolling through pattern lines.

